

# Style List

**GW-8** Version 2

STYLE SELECT Button	No.	Style Name	Category	Tempo
[POP/ROCK]	001	StraightRock	ROCK	136
	002	SteadyRock	ROCK	110
	003	Rock	ROCK	158
	004	Crossover	ROCK	180
	005	LatinRock	ROCK	124
	006	HardRock	ROCK	123
	007	AmericanHR	ROCK	128
	008	ShuffleRock	ROCK	160
	009	NewWave	ROCK	122
	010	GramRock	ROCK	121
	011	ShuffleHR	ROCK	148
	012	WestCourst	ROCK	94
	013	SurfRock	ROCK	150
	014	Riverpool	ROCK	132
	015	Alternative 1	ROCK	105
	016	Alternative2	ROCK	125
	017	PopRock	ROCK	123
	018	EuroPopRock	ROCK	120
	019	Acoustic	ROCK	92
	020	RockShuffle	ROCK	91
	021	AOR	8BEAT	95
	022	AorPop	8BEAT	68
	023	BritPop	8BEAT	85
	024	80sBritishPop	8BEAT	114
	025	PianoBallad	8BEAT	68
	026	PoppinBallade	8BEAT	80
	027	AorBallade	8BEAT	87
	028	HardRockBallade	8BEAT	68
	029	SmilePop	8BEAT	122
	030	OrganBallade	8BEAT	75
	031	GermanPop	8BEAT	180
	032	GuitarPop	POP	85
	033	RockPop	POP	94
	034	DiscoPop	POP	130
	035	68Pop	POP	64
	036	OrientalPop	POP	97
	037	Irish	POP	110
	038	ItalianPop	POP	110
	039	EasyPop	16BEAT	73
	040	16BeatPop	16BEAT	110
	041	SoulBallad	16BEAT	80
	042	PopBallad	16BEAT	69
	043	24BeatPop	16BEAT	85
	044	NightPop	16BEAT	76
	045	LatinPop	16BEAT	102
	046	LightPop	16BEAT	96
	047	FeelGood	16BEAT	103
	048	GroovyPop	16BEAT	103
	049	AcidJazz	16BEAT	95
	050	Motown	16BEAT	95
	051	Unplugged	16BEAT	87

STYLE SELECT Button	No.	Style Name	Category	Tempo
[POP/ROCK]	052	GuitarBallad	BALLAD	84
	053	EPBallad	BALLAD	62
	054	Ballad	BALLAD	66
	055	Lounge	BALLAD	90
	056	SmoothBallad	BALLAD	80
	057	Techno1	DANCE	140
	058	Techno2	DANCE	136
	059	Techno3	DANCE	140
	060	House1	DANCE	125
	061	House2	DANCE	128
[DANCE]	062	SoulPop	DANCE	118
	063	AcidDance	DANCE	102
	064	Disco	DANCE	124
	065	Rap	DANCE	97
	066	Reggaeton	DANCE	88
	067	CoolRap	DANCE	98
	068	Hiphop1	DANCE	80
	069	Hiphop2	DANCE	160
	070	Hiphop3	DANCE	95
	071	R&B1	DANCE	113
[JAZZ/LATIN]	072	R&B2	DANCE	84
	073	Reggaepop	DANCE	86
	074	R&B	DANCE	87
	075	Electronic	DANCE	130
	076	R&BDance	DANCE	90
	077	DancePop	DANCE	118
	078	Breakbeat	DANCE	126
	079	JazzBallad1	JAZZ	70
	080	BigBand1	JAZZ	118
	081	JazzClub	JAZZ	122
	082	BigBandBallad	JAZZ	76
	083	JazzWaltz	JAZZ	140
	084	FastSwing	JAZZ	220
	085	JazzBallad2	JAZZ	60
	086	SmoothJazz	JAZZ	98
	087	BigBand2	JAZZ	82
	088	FolkJazz	JAZZ	88
	089	SoulJazz	JAZZ	120
	090	LuvBossa	LATIN	130
	091	MidBossa	LATIN	150
	092	UpBossa	LATIN	170
	093	UpSamba	LATIN	100
	094	BossaPop	LATIN	98
	095	Salsa	LATIN	182
	096	Guarach	LATIN	110
	097	Merengue	LATIN	150
	098	Bachata	LATIN	120
	099	Jogetmly	LATIN	116
	100	TropicalPop	LATIN	116
	101	Caribbean	LATIN	116

Style List

FILE SELECT Button	No.	Style Name	Category	Tempo
[TRADITIONAL]	102	Blues	TRADITIONAL	97
	103	70sR&B	TRADITIONAL	102
	104	RocknRollLullaby	TRADITIONAL	75
	105	FunkSoul	TRADITIONAL	104
	106	Reggae	TRADITIONAL	95
	107	Country	TRADITIONAL	240
	108	CountryPop	TRADITIONAL	138
	109	Cajun	TRADITIONAL	162
	110	Old6_8	TRADITIONAL	128
	111	OldiePop	TRADITIONAL	114
	112	Oldie	TRADITIONAL	186
	113	Gospel	TRADITIONAL	108
	114	Schlager	TRADITIONAL	120
	115	March	TRADITIONAL	122
	116	Polka	TRADITIONAL	132
	117	PolkaPop	TRADITIONAL	140
	118	Filmscore	TRADITIONAL	64
	119	70sDisco	BALLROOM	104
	120	BigSamba	BALLROOM	126
	121	Rockabilly	BALLROOM	166
	122	Boogie	BALLROOM	126
	123	Twist	BALLROOM	142
	124	WienerWaltz	BALLROOM	160
	125	EnglishWaltz	BALLROOM	104
	126	Tango	BALLROOM	125
	127	Musette	BALLROOM	200
	128	Mambo	BALLROOM	186
	129	Rhumba	BALLROOM	110
	130	Shuffle	BALLROOM	140
[WORLD]	131	HUN Beat1	WORLD(EURO)	134
	132	HUN Beat16	WORLD(EURO)	74
	133	Csardas	WORLD(EURO)	123
	134	HUN Disco1	WORLD(EURO)	147
	135	HUN Disco2	WORLD(EURO)	136
	136	HUN Disco3	WORLD(EURO)	140
	137	HUN Disco4	WORLD(EURO)	160
	138	HUN Disco5	WORLD(EURO)	139
	139	HUN Disco6	WORLD(EURO)	141
	140	HUN Disco7	WORLD(EURO)	133
	141	HUN Discofox	WORLD(EURO)	136
	142	Mulatos	WORLD(EURO)	136
	143	Ragga	WORLD(EURO)	104
	144	HUNRock&Roll	WORLD(EURO)	182
	145	Roma kv	WORLD(EURO)	103
	146	HUN Twist	WORLD(EURO)	172
	147	HUN Rock1	WORLD(EURO)	135
	148	HUN Rock2	WORLD(EURO)	135
	149	HUN Polka	WORLD(EURO)	130
	150	Latin-pop1HU	WORLD(EURO)	113
	151	Latin-pop2HU	WORLD(EURO)	113
	152	PL Dziew 6-8	WORLD(EURO)	106

153	PL Brathanki	WORLD(EURO)	168
154	PL Slow Pop	WORLD(EURO)	111
155	PL WiosnaDnc	WORLD(EURO)	128
156	PL Sunshine	WORLD(EURO)	115
157	PL Dance Hit	WORLD(EURO)	131
158	PL CoCo Beat	WORLD(EURO)	96
159	Disco Polka	WORLD(EURO)	140
160	PL GroovRock	WORLD(EURO)	97
161	PL Laendler	WORLD(EURO)	208
162	PL Polka	WORLD(EURO)	124
163	PL Pop 1	WORLD(EURO)	155
164	PL Pop 2	WORLD(EURO)	99
165			

[WORLD]

STYLE SELECT Button	No.	Style Name		Category	Tempo
[WORLD]	204	Gold Jive	★	WORLD(EURO)	174
	205	Gold Tango	★	WORLD(EURO)	132
	206	Gold Bossa	★	WORLD(EURO)	124
	207	Gold Samba	★	WORLD(EURO)	100
	208	Gold Cha Cha	★	WORLD(EURO)	128
	209	Gold Rhumba	★	WORLD(EURO)	100
	210	Gold Euro March	★	WORLD(EURO)	120
	211	Gold Swing	★	WORLD(EURO)	139